


# Opravná sada I93362008



67•	Zackenring	1
66•	Filter	1
65•	Sicherungsring	1
60•	O-Ring 28 x 2,5 (D <sub>i</sub> x d)	1
58•	O-Ring 6 x 4 (D <sub>i</sub> x d)	1
55•	O-Ring 20 x 2,5 (D <sub>i</sub> x d)	2
52•	O-Ring 5,5 x 2,5 (D <sub>i</sub> x d)	1
48•	Schraube	4
47•	Sechskantmutter	4
42•	O-Ring 8 x 4 (D <sub>i</sub> x d)	1
41•	O-Ring 8 x 3 (D <sub>i</sub> x d)	1
40•	Zylinderschraube	3
39•	Scheibe	3
38•	O-Ring 21,5 x 3 (D <sub>i</sub> x d)	1
37•	Sechskantschraube	4
36•	O-Ring 12,5 x 2,7 (D <sub>i</sub> x d)	1
33•	O-Ring 58 x 4 (D <sub>i</sub> x d)	1
32•	O-Ring 103 x 3 (D <sub>i</sub> x d)	1
31•	O-Ring 84 x 3,5 (D <sub>i</sub> x d)	3
30•	Federscheibe	1
29•	Linsenschraube	1
26•	O-Ring 53 x 3 (D <sub>i</sub> x d)	1
24•	Federteller	1
23•	O-Ring 54 x 4 (D <sub>i</sub> x d)	1
20•	Ring	1
19•	Ventilteller	1
17•	O-Ring 17 x 3 (D <sub>i</sub> x d)	1
15•	O-Ring 46 x 3 (D <sub>i</sub> x d)	1
13•	O-Ring 68 x 4 (D <sub>i</sub> x d)	1
11•	Sprengring	1
9•	Sprengring	1
6•	Sprengring	1
Pos. Rep.	Benennung Désignation	Stück Qté.